



DMX CHART – LUXIBEL B BLINDED

1 Channel Mode

Channel	Value	Function
CH1	0-255	Dimmer – 0-100%

2 Channel Mode

Channel	Value	Function
CH1	0-255	Dimmer – 0-100%
CH2	0-255	Dimmer – 0-100%

4 Channel Mode

Channel	Value	Function
CH1	0-255	Dimmer – 0-100%
CH2	0-255	Dimmer – 0-100%
CH3	0-255	Master Dimmer – 0-100%
CH4 FLASH	0-5	Open
	6-123	Flash rate, slow to fast
	124-127	Open
	128-185	2 LEDs random strobe at the same time
	186-190	Open
	191-249	2 LEDs random strobe respectively
	250-255	Open

6 Channel Mode

Channel	Value	Function
CH1	0-255	Dimming coarse – 0-100%
CH2	0-255	Dimming fine
CH3	0-255	Dimming coarse 0-100%
CH4	0-255	Dimming fine
CH5	0-255	Master Dimmer 0-100%
CH6 FLASH	0-5	Open
	6-123	Flash rate, slow to fast
	124-127	Open
	128-185	2 LEDs random strobe at the same time
	186-190	Open
	191-249	2 LEDs random strobe respectively
	250-255	Open

8 Channel Mode

Channel	Value	Function	
CH1	0-255	LED1 Dimming coarse 0 -100%	
CH2	0-255	LED1 Dimming fine	
CH3	0-255	LED2 Dimming coarse 0 -100%	
CH4	0-255	LED2 Dimming fine	
CH5	0-255	Master LED Dimmer 0 -100%	
CH6	0-5	Open	Flash LED 1
	6-123	Flash Rate, slow to fast	
	124-127	Open	
	128-249	LED1 random strobe slow to fast	
	250-255	Open	
CH7	0-5	Open	Flash LED2
	6-123	Flash Rate, slow to fast	
	124-127	Open	
	128-249	LED2 random strobe slow to fast	
	250-255	Open	
CH8	0-63	According to menu	Dimmer speed
	64-127	Fast	
	128-191	Smooth	
	192-255	Und	